



Duplex Wireless System

BATTERY CHARGING

- + System includes rechargeable batteries.
- + Plug charger AC adapter into charging base and into wall outlet.

IMPORTANT: There are two AC adapters supplied with this system. The Com-Center adapter will fit ONLY the Com-Center.

The Charger adapter will fit ONLY the Charger.

- + Batteries should snap into charging slot securely.
- + Charge time 2 - 4 hours.

LED Indicators:

- GREEN: Fully charged
- RED: Charging
- RED Flashing: Battery Faulty
- NO LIGHT: Battery improperly inserted

Charge up to 8
Headset
batteries



Charge up to 2
Com-Center
batteries

BATTERY FACTS

- + COMSTAR high capacity Lithium batteries provide up to 10 hours of operation.
- + Lithium batteries do not develop a memory, so do not need to be drained after use.

IMPORTANT TIPS

Microphone Placement

- + COMSTAR headsets include a special noise cancelling microphone. For optimum performance place directly in front of, and approximately 1 - 2" from the user's mouth.



Com-Center Placement

- + Line of sight: for optimum range, position the Com-Center so that the radio signals have a clear path to the wireless headset/radios.

Storage

- + Lithium batteries should be at least partially charged when stored for long periods.

CAUTION

Compartment on bottom of Com-Center houses switches for factory programming. Call Eartec for more information: 1-800-399-5994.



EARTEC[®]

145 Dean Knauss Drive
Narragansett, RI 02882
Tel: 1-800-399-5994
In RI: 401-782-4966
Fax: 401-789-7300
www.eartec.com

Operating Instructions

COM-CENTER START

- + Attach AC power cord to Com-Center, then plug into the nearest wall outlet.
- + If wall outlet is not available insert rechargeable battery into slot at back of Com-Center (silver contacts must be in proper position).
- + OR use five Brand Name AA Batteries in battery sled (provides up to 6 hours of operation).
- + Turn Com-Center ON (switch on back panel).

Note: If rechargeable battery and AC power cord are used simultaneously, the battery will receive a trickle charge while system is in use.

COM-CENTER FACTS

Line of Sight

- + For optimum range, position the Com-Center so that the radio signals have a clear path to the wireless Headsets.

Dual Channel Feature

- + Red & Green LED lights indicate two separate channels are in use.

- + Amber LED light indicates conference feature is in use.



Note: Switch connects both channels, linking all headsets.

COMPAK SERIES START

- + Plug headset into the side of the COMPAK transceiver.
- + Insert battery into COMPAK.
- + COMPAK will automatically turn ON.



"ALL-IN-ONE" SERIES START

- + Insert battery into headset.
- + Headset will automatically turn ON.



Note: Slide battery into compartment bottom first, then press top to snap into place. Push latch up to eject.

BLUE LED INDICATIONS

- + Flashing blue LED on headset or COMPAK indicates automatic tuning to Com-Center signal.
- + When the Com-Center is ON the headset / COMPAK LED will automatically change to solid blue (indicating communication).
- + Solid blue LED means headset or COMPAK is communicating.

Eartec XT Series

HEADSET / COMPAK CONTROLS

Power Button

After the battery is installed, the power button is used to turn the headset "ON" and "OFF".

- + OFF by pressing & holding until LED goes out.
- + ON by quick clicking, LED illuminates.

MIC Mute Button

Power Button

Volume Controls

MIC Mute Button



Volume

- + Volume control buttons adjust to any of five settings.

MIC Mute - grey button

- + Click MIC button to mute microphone, audible tone confirms change.
- + Repetitive beep indicates battery low.